



QUICK INSTALLATION GUIDE FOR USING THE TELCO PORT AS LINK

Connections will be made with equipment off, then all turned on at the end of this guide.

Please refer to your manual for your radio to setup the following:

- Setup your radio for 4800 baud serial communications on its COM port.
- Return your radio to VFO mode, meaning not in memory or menu modes.
- Turn off your radio.
- Connect the supplied microphone cable (or accessory cable depending on the radio) into your radio. and the other end(RJ-45) into the radio port on the RBC-212.
- Connect the supplied serial cable to connect to your radios COM port and the other end into the "Serial Port" on the RBC-212. Depending on your radio, this supplied cable might have a level converter built-in such as ICOM's CI-V port.
- Connect the supplied telephone cable to the telephone line you wish to use into the TELCO jack on the RBC. Make sure the end with the large filter on the cable is closest to the RBC.
- Connect the supplied power supply into the the wall and the other end into the RBC.
- Set the Answer switch on the front panel of the RBC to "ON".
- Turn your radio on.
- Set the mic gain on the front panel at about 11:00 using indentation on the shaft.
- Call the telephone number connected to the RBC with any other land line or cell phone. After about 2 rings the RBC will auto-answer. When prompted, enter 1234.
- Use the supplied cheat sheet for instructions on how to operate your radio remotely.
- Spend some time in front of your radio with your phone to learn how the codes on the cheat sheet will control your radio. Have Fun!

Questions? Call Techsupport at 954-261-8968.