

RECEIVE #1

1 UP 100HZ	2 SCAN UP MEDIUM	3 SCAN UP FAST
4 DOWN 100HZ	5 SCAN DOWN MEDIUM	6 SCAN DOWN FAST
7 ⁺² MEMORY SET	8 UP 500HZ	9 ⁺² MEMORY RECALL
* ⁺⁸ SET VFOA PLAY VFOA	0 DOWN 500HZ STOP	# ⁺¹ MENU SELECT PLAY VFOB

ANTENNA #2

1 ANTENNA 1	2 ANTENNA 2	3 TUNER IN
4 ⁺³ SWITCH TO ANT1+ROTATE	5 ⁺³ SWITCH TO ANT2+ROTATE	6 TUNER OUT
7 AUX 1 ON	8 AUX 1 OFF	9 TUNE ANTENNA
* ⁺⁸ SET VFOA PLAY VFOA	0 STOP ROTATION	# ⁺¹ MENU SELECT PLAY VFOB

FILTER #3

1 ANTENUATOR	2 PRE AMP	3 NOISE BLANKER
4 NOISE REDUCTION	5 AUTO NOTCH	6 BEAT CANCEL
7	8	9 ⁺¹ MODE SELECT
* ⁺⁸ SET VFOA PLAY VFOA	0 FUNCTION OFF ALL OFF	# ⁺¹ MENU SELECT PLAY VFOB

TRANSMIT #4

1 TRANSMIT	2 SPEECH COMP. ON	3 VOX ON
4 TONE ON	5 SPLIT ON	6 AMP ON
7 ⁺² SET TONE FREQ (SEE CHART)	8 ⁺¹ SHIFT: S,+, -	9 ⁺² RECALL MEMORY
* ⁺⁸ SET VFOA PLAY VFOA	0 ⁺¹ RECEIVE FUNCTION OFF	# ⁺¹ MENU SELECT PLAY VFOB

SETTINGS #5

1 GENERAL	2 ADVANCED	3 EXTRA
4 PASSWORD	5 RESET RADIO	6
7 ⁺¹ SET # OF RINGS	8 VOICE VOLUME UP	9
* ⁺⁸ SET VFOA PLAY VFOA	0 VOICE VOLUME DOWN	# ⁺¹ MENU SELECT PLAY VFOB

AUXILLARY #6

1 ON	2 ⁺¹ AUX 2	3 ⁺¹ AUX 3
4 ⁺¹ AUX 4	5 ⁺¹ AUX 5	6 ⁺¹ AUX 6
7 ⁺¹ AUX 7	8 ⁺¹ AUX 8	9 ⁺¹ AUX 9
* ⁺¹ SET VFOA PLAY VFOA	0 ⁺¹ OFF	# ⁺¹ MENU SELECT PLAY VFOB